



# Beta Coolant Spigot Tool

Part Number: AB-50066

All 2020+ RR,RR-S

## Installation Instructions:



1. Drain the cooling system by removing the lower water pump cover bolt. Loosen the radiator cap to start the coolant flow. Use a container to catch the coolant re install the bolt and washer and torque to 10 nm.
2. Remove the seat, remove radiator shrouds, fuel tank, radiators, coolant hoses.
3. Install Spigot Removing tool into coolant fitting, and place a wet towel in behind to prevent melting/burning other components.
4. Heat for approximately 30 seconds, use 17mm socket to remove fitting form engine case.
5. Clean all debris from engine case and spigot fitting before re installation!
6. Apply Blue Loctite and re install the fitting into the engine case.
7. Use 17 mm Socket and Beta Spigot tool to tighten fitting, torque to 30 Nm.
8. Reinstall radiators, hoses, fuel tank, radiator shrouds, and seat. Refill coolant.
9. Your bike is ready for use!