



STT-2025-1

How to Install Lift Strap on RR X-Pro Models

Follow these instructions below to install the lift strap on the RR X-Pro models.



1. Remove the front wheel assembly.
2. Remove the front brake master cylinder from the handlebars by removing the half clamp to allow you to slide down the RH fork leg.



3. Loosen the RH pinch bolts on the top & bottom triple clamps.
4. Slide the RH fork leg down to slip the strap over the top of the fork leg.



5. Slide the RH fork leg back into place & torque the pinch bolts to proper specs.



6. Loosen the LH pinch bolts on the top & bottom triple clamps.
7. Slide the LH fork leg down to slip the strap over the top of the fork leg.



8. Slide the left fork leg back into place & torque the pinch bolts to proper specs.



9. Reinstall the front brake master cylinder to the handlebars.

10. Reinstall the front wheel assembly & torque axel nuts to proper specs.